

















**WARNING**

To avoid injury during assembly, disassembly, use, adjustment and/or movement of the PRIMED Lacrosse Rebounder, the following warnings **MUST** be observed at all times:

- Two competent adults are required to assemble, disassemble, adjust, and/or locate the Lacrosse Rebounder.
- Extreme caution and appropriate judgment should **ALWAYS** be exercised when assembling, disassembling, using, adjusting, or locating the Lacrosse Rebounder.
- **NEVER** climb on or hang from the Lacrosse Rebounder.
- **ALWAYS** anchor the Lacrosse Rebounder as instructed prior to use. An unsecured rebounder can cause serious injury.
- Bungee cord net loops will be under tension and must be attached and/or detached carefully.
- The Lacrosse Rebounder should be placed on a flat surface that is suitable for play while ensuring maximum user safety.
- Fully disassemble the Lacrosse Rebounder for seasonal storage.
- Do not leave the Lacrosse Rebounder outdoors in inclement weather as moisture and other elements may adversely affect the performance of the unit.

- Ensure all components are properly assembled prior to use.
- Examine your Lacrosse Rebounder regularly for wear and tear. Discontinue use immediately if any defect is found.
- Keep away from fire and heat sources.
- **CHOKING HAZARD!** Unassembled parts may be a choking hazard for children 3 years and younger. Adult assembly and supervision is required.
- Failure to follow the above mentioned Warnings may result in injury.

1.PACKAGE CONTENTS:

PART NO.	PHOTO	DESCRIPTION	SIZE: 8' X 4'	
			SPEC.	Q' TY
1		Steel tube	1.5" X34.8"	2PCS
2		Steel tube	1.5" X32"	1PCS
3		Steel tube	1.5" X(32" +10.7")	1PCS
4		Steel tube	1.5" X(32" +10.7")	1PCS
5		Steel tube	1.5" X34.8"	2PCS
6		Steel tube	1.5" X32"	1PCS
7		Steel tube	1.5" X32.6"	1PCS
8		Steel tube	0.98" X39.4"	2PCS
9		Steel tube	1.1" X35.4"	2PCS
10		Steel tube	1.1" X35.6"	1PCS
11		Steel tube	1.1" X31.9"	1PCS
12		Steel tube	0.98" X31.9"	1PCS
13		Bolts and nuts	M6X2.64"	2PCS
14		Bolts and nuts	M6X1.57"	2PCS
15		Bungee cord		48PCS
16		net		1PCS




FIGURE 1

Connect tubes as shown in Figure 1.




FIGURE 2

Connect support tubes part 8 and 9 as shown in Figure 2, tighten up the support tubes using nuts and bolts, part number 13 and 14.




FIGURE 3

Install height and angle adjustment tubes 11 and 12. Connect tube 11 to tube 7, then connect 12 to tube 10. Tighten up the parts by using nuts and bolts, part number 13 and 14.

Connect the net to the frame tube.

1. Attach bungee cords to rebounding net by looping bungee cords through net and looping back through bungee.
2. Pull bungee cord to frame tube (Fig A).




3. Wrap the hook around the tube (Fig B).



4. Hook bungee cord onto the net, around frame tube (Fig C).



5. Find the buckle and hook and loop Strap on the tarp at the rear side (Fig D).



6. Insert the strap into the buckle (Fig E).



7. Secure the strap with hook and loop closure (Fig F).





Limited Warranty

Limited Warranty

Dick's Sporting Goods, Inc. (the "Company") warrants this product to be free from defects in workmanship and materials under normal use and conditions for a period of ONE YEAR FROM THE DATE OF ORIGINAL PURCHASE. This Limited Warranty is not transferable and is available only for the original purchaser of the Product. The Company's obligation under this warranty is limited to replacing or repairing the Product, at the discretion of the Company.

EXCEPT AS SPECIFICALLY SET FORTH IN THIS LIMITED WARRANTY, DICK'S SPORTING GOODS, INC. MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE WITH RESPECT TO ANY PRODUCT.

Material Covered

Except as detailed below, this Limited Warranty covers defects in materials and workmanship. This Limited Warranty is void if the Product is:

- ° Damaged through improper use, negligence, abuse, misuse, transportation, damage, acts of nature, or accident, to include failure to follow the assembly and or operating instructions supplied with the product.
- ° Used in commercial or rental applications.
- ° Modified or repaired by anyone not authorized by the Company.

Material Not Covered

This Limited Warranty does not cover expendable items including but not limited to: Batteries, light bulbs, fuses, accessories, and other items that experience wear as a result of normal use.

Terms of Coverage

If during the one year LIMITED WARRANTY period, the Company deems any part or component of the Product to be defective, the Company will repair the Product without charge, or at the option of the Company, will replace the Product with new product, either the same or an equivalent item.

The Company's liability is limited to the repair or replacement, at its option of any defective product.

THE COMPANY ASSUMES NO RESPONSIBILITY NOR LIABILITY FOR INDIRECT OR CONSEQUENTIAL DAMAGES OF ANY KIND.

THIS LIMITED WARRANTY IS MADE IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, EXCEPT AS OTHERWISE PROVIDED BY APPLICABLE LAW.

Please direct all Product inquiries to:

Dick's Sporting Goods, Inc.
345 Court Street
Coraopolis, PA 15108
Customer Service
1 866 677 4771
customer.service@dcs.com